

# ROKSAN

ANALOGUE ACCESSORIES & UPGRADES

ANALOGUE


Thank you for purchasing your Roksan Xerxes Record Player upgrade 'BLOB' kit. Please read all installation and operating instructions carefully before use.

Only use genuine Roksan parts for all replacement, upgrade or maintenance to ensure optimum performance and longevity of your cherished record player.

## Record Player: Suspension 'BLOB'

Xerxes (Original)

# XB 3i




Roksan Audio Limited Jubilee Close Townsend Lane London NW9 8XD ENGLAND  
Tel +44 (0)20 8900 6801 Fax +44 (0)20 8205 2644 Email [info@roksan.co.uk](mailto:info@roksan.co.uk) Website [www.roksan.co.uk](http://www.roksan.co.uk)

Roksan Xerxes Record Player upgrade 'BLOB' kit fitting instructions.

1. Remove existing 'BLOB's and the top plinth grommet/washer supports (x3)

2. Replace with the new XB 3i 'BLOB's as shown observing the colour codings



3. Place the top plinth support mounts on the new fitted 'BLOB's as shown

4. Carefully place the top plinth on the new fitted 'BLOB' assemblies

5. Follow Xerxes user/set-up manual to ensure correct alignment of your Xerxes record player top plinth

6. Check all other alignments and fittings to ensure optimum performance of your upgraded Xerxes record player



*Enjoy your music...*

For any queries contact your appointed Roksan retailer, distributor or Roksan Audio.

**Made in England**

All specifications are liable to change without prior notice. E & OE